



INSTRUCTION SHEET

FINCH WALL CONDUIT CANOPY



689-20080

PAGE 1 OF 1

WARNING - RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY. FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL SPECIFICATIONS. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.

RETAIN THESE INSTRUCTIONS FOR MAINTENANCE REFERENCE.

- 1** LOOSEN (DON'T REMOVE) SET SCREW TO SEPARATE CROSSBAR FROM FIXTURE
- 2** ATTACH CROSSBAR TO JUNCTION BOX (B.O.) WITH MOUNTING HARDWARE (B.O.)
- 3** FEED FIXTURE WIRES THROUGH CROSSBAR THEN SPLICE TO INCOMING WIRES
- 4** SLIDE FIXTURE OVER CROSSBAR WITH SET SCREW POINTED DOWN, REMOVING CANOPY KNOCKOUTS AS NEEDED
- 5** ADJUST FIXTURE TILT THEN TIGHTEN SET SCREW



Amerlux, 178 Bauer Drive, Oakland, N.J. 07436, T: 973-882-5010, F: 973-882-2604 www.amerlux.com