



Maintenance -

Reflectors do not have to be removed except for driver replacement or other maintenance. Disconnect power before servicing. To assemble (disassembly in reverse order as applicable):



1. Connect LED wiring harness (Red/Black). 2. Insert reflector by tilting it into housing (<u>caution</u>: do not pinch wires.)



 Secure reflector to upper area of extrusion via 8-32 screws.
Install lens. Starting at (1) end, squeeze lens legs IN to snap LENS in place, and continue pressing upwards across the length of the fixture until lens is secure.


MAKE SURE TO DISCONNECT ALL ELECTRICAL CONNECTIONS BEFORE SERVICING.


WARNING: Electrostatic and polarity sensitive device. Use caution while handling and wiring.


- 1.) LED Fixture:
- 2.) LED Replacement:
- 3.) Driver maintenance.

Consult Ameriux for LED maintenance. For LED board replacement reference 689-0394 Instruction Sheet Drivers are located on tray beneath indirect reflectors. Remove reflector mounting screws to access. For **programmable** driver replacement please specify: **Manufacturer**, **Model No.** and **Current Setting** (_____mA). See 710-0134 Wiring Schematic for more details.


Amerlux, LLC. - 178 Bauer Drive, Oakland NJ 07004 - T: 973-882-5010 - F: 973-882-2605 www.amerlux.com









Amerlux, LLC. - 178 Bauer Drive, Oakland NJ 07436 - T: 973-882-5010 - F: 973-882-2605 www.amerlux.com




2. Assembling Continuous Rows- (Socket/reflector assemblies must be removed. All fixtures must be fully supported by rod or blocking.)



Amerlux, LLC. - 178 Bauer Drive, Oakland NJ 07436 - T: 973-882-5010 - F: 973-882-2605 www.amerlux.com





Amerlux, LLC. - 23 Daniel Road East, Fairfield NJ 07004 - T: 973-882-5010 - F: 973-882-2605 www.amerlux.com