

# INSTRUCTION SHEET

689-9006

DC214DC/DC216, DC214FC/DC216FC INSTALLATION

**WARNING** - RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY. FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL SPECIFICATIONS. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.

**RETAIN THESE INSTRUCTIONS FOR MAINTENANCE REFERENCE.**

## TOOLS REQUIRED:

1. Allen Wrench
2. Philips Screw driver

## **Notice to installer for DC214:**

1. For pole top applications only.
2. Slip fits 4" OD x 2.75" post or tenon. (3" OD x 2.75 CUSTOM)

LED module and integral driver provided by Amerlux

## LUMINAIRE INSTALLATION

1. **Ensure power is turned off to the luminaire connection point.**
2. Route the luminaire wiring through to the pole base and slip luminaire over the top of the pole.
3. Secure luminaire by tightening (6) set screws on pole fitter, evenly.
4. Make supply wiring connections to luminaire wire in pole base:  
MAIN VOLTAGE SUPPLY WIRE TO BLACK LUMINAIRE WIRE  
NEUTRAL (COMMON) SUPPLY WIRE TO WHITE LUMINAIRE WIRE  
GREEN GROUND WIRE TO GREEN LUMINAIRE WIRE.
5. Dimming (if applicable): DIMMING CONTROL WIRE (+) TO POSITIVE LUMINAIRE DIM CONTROL WIRE DIMMING CONTROL WIRE (-) TO NEGATIVE LUMINAIRE DIM CONTROL WIRE

